



## Women's Axis Soft Shell Jacket

	XS	S	M	L	XL	2XL	3XL
<b>BODY LENGTH - FROM CB NECK</b>	24 1/2	25	25 1/2	26 1/4	27	27 5/8	28 1/4
<b>ACROSS SHOULDER - FROM BACK</b>	14 3/4	15 1/4	15 3/4	16 1/2	17 3/8	18 1/2	19 5/8
<b>CHEST WIDTH - 1" BELOW ARMHOLE</b>	17 3/4	18 3/4	19 3/4	21 3/4	23 3/4	26 3/8	28 7/8
<b>WAIST WIDTH</b>	16 1/2	17 1/2	18 1/2	20 1/4	22 1/4	24 3/4	27 1/4
<b>BOTTOM OPENING WIDTH - STRAIGHT</b>	19 1/2	20 1/2	21 1/2	23 1/4	25 1/4	27 3/4	30 1/4
<b>SLEEVE LENGTH FROM CB - EXCLUDING CUFF</b>	31 3/4	32 1/4	32 3/4	33 3/8	34	34 1/4	34 1/2

**Key to Commonly Abbreviated Spec. Information** (all measurements are in inches)

**CB** = Center Back

**Chest 1" down** = means you measure the front of the garment 1" down from the armhole

**1/2** = Measure only the front of the garment, then double that measurement to get the total circumference

**Relaxed** = Do not stretch the garment if it has elastic to measure, simply leave the elastic relaxed and measure

**Stretched** = Stretch the garment if it has elastic to measure, measure stretched