



Men's Axis Soft Shell Jacket

	S	M	L	XL	2XL	3XL
BODY LENGTH FROM CB NECK	28	29	30	30 3/4	31 1/2	32 1/2
ACROSS SHOULDER - FROM BACK	17 1/4	17 3/4	18 1/4	19 1/4	20 1/4	21 1/4
CHEST WIDTH 1" DOWN	21 3/4	22 3/4	23 3/4	25 3/4	27 3/4	29 3/4
BOTTOM OPENING WIDTH RELAXED 1/2	21 1/4	22 1/4	23 1/4	25 1/4	27 1/4	29 1/4
SLEEVE LENGTH FROM CB	33 1/2	35	36 1/4	36 3/4	37 1/4	37 3/4

Key to Commonly Abbreviated Spec. Information (all measurements are in inches)

CB = Center Back

Chest 1" down = means you measure the front of the garment 1" down from the armhole

1/2 = Measure only the front of the garment, then double that measurement to get the total circumference

Relaxed = Do not stretch the garment if it has elastic to measure, simply leave the elastic relaxed and measure

Stretched = Stretch the garment if it has elastic to measure, measure stretched